


# **B940W Slim Touch Keypad**





## **System overview**

- · For commercial use, install the keypad in building entrances and areas with unrestricted access. Mounting a keypad near exterior doors in hotel or business lobbies allows people to identify the type and location of the emergency.
- For residential use, install the keypad near the front and rear entrances to the home. Install additional keypads in a kitchen or in a bedroom.
- Use multiple keypads in a large building with many separate areas of security. Program multiple keypads to control multiple areas.
- Audible tones from the keypad sounder alert personnel to fire events and assist fire fighters in locating the keypad.

# **Notice**

Audible fire-generated keypad sounder alerts occur when fire detection devices are installed on the same system.











- ► Color graphic touch screen display
- ► Slim, modern design blends with any decor
- ► Combination of simple icons and text for easy display

## **Functions**

### Display

The touch screen display uses icons, words, numbers, and symbols to show the status of the security system and for interacting with the security system. When several events occur, the keypad scrolls through each event in order of priority.

## User icons and keys

The keypad's home screen shows the system status at a glance using a large icon. The user can change the system status by touching this icon. The touch screen display also offers icons on the ribbon bar. These visually pleasing graphical icons are easy to use for accessing menus and other options. The keypad screen has numeric keys and one function [CMD] key. When pressed, keys emit a beep. Use the keyboard for entering passcodes, activating commands, and entering alphanumeric characters.

#### **Audible tones**

The keypad has a built-in speaker that produces several distinct warning tones. The tones are unique to each different type of event, thereby enabling the user to recognize a given event by hearing its associated tone. The keypad backlight illuminates when it emits an audible tone. Users can use a passcode to silence the tone.

#### **Status indicators**

The status indicators on the keypad provide a quick visual reference for system status.



The indicator lights when the system is ready to turn on (arm).

a	The indicator lights when the system is on (armed).
Δ	The indicator lights when there is a trouble condition.
GAS	The indicator lights when dangerous gases are present including carbon monoxide (NFPA 720).
#	The indicator lights when the system has power.



## **Notice**

The Gas indicator feature is operational when a separate CO or gas detector is installed and resides on the same system.

## Installation/configuration notes

## **Power supply**

A compatible control panel supplies the power and data requirements to the keypad through a four-wire connection.

## Mounting and wiring

Mount in dry indoor locations.

Includes a slim mounting plate for recessed wiring, and a surface mounting plate for surface mounting and wiring.

#### **Molex connection**

The Molex connection wires provide power and communication to the control panel through the control panel's SDI2 4-wire bus connection. The Molex connection for this device is specifically made for the keypad, and not supported on any other device.

## **Compatible control panels**

B9612G

B8612G

B9512G

B8512G

B6612

B6512

B5612

B4612

B5512 firmware v2.03 and higher

B4512 firmware v2.03 and higher

B3512 firmware v2.03 and higher

D9412GV4/D7412GV4 v2.03 and higher

## **Parts included**

Quantit y	Component
1	Keypad
2	Mounting plates (slim and surface)
1	Hardware pack

Quantit y	Component
1	Quick installation guide

# **Technical specifications**

#### **Properties**

Dimensions	76 mm x 140 mm x 10 mm (3.0 in x 5.5 in x 0.40 in)
Weight	0.11 kg (3.88 oz)
Material	Hard plastic
Display window	Touch screen Multi-line messages
Indicators	Status indicators  Main icon  Warning and indicating tones

#### **Environmental considerations**

Relative humidity	5% to 93% at +32°C (+90°F) non- condensing
Temperature (operating)	0°C to +50°C (+32°F to +122°F)

## **Power requirements**

Voltage (input)	12 VDC nominal
Standby	250 mA
Alarm	365 mA

## Wiring

Terminal wire size	18 AWG to 22 AWG (1.02 mm to 0.65 mm)
SDI2 wiring length	Maximum distance - wire size (unshielded wire only):
	46 m (150 ft) - 0.65 mm (22 AWG)
	119 m (390 ft) - 1.02 mm (18 AWG)

## **Ordering information**

## **B940W Slim Touch Keypad**

SDI2 compatible touch screen keypad with function keys.

Available languages: English, Chinese, Dutch, French, German, Greek, Italian, Hungarian, Polish, Portuguese, Spanish, Swedish.

Order number **B940W | F.01U.358.360** 

## Represented by:

Europe, Middle East, Africa: Bosch Security Systems B.V. P.O. Box 80002 5600 JB Eindhoven, The Netherlands Phone: + 31 40 2577 284 www.boschsecurity.com/xc/en/contact/ www.boschsecurity.com Germany:
Bosch Sicherheitssysteme GmbH
Robert-Bosch-Ring 5
85630 Grasbrunn
Tel.: +49 (0)89 6290 0
Fax:+49 (0)89 6290 1020
de.securitysystems@bosch.com
www.boschsecurity.com

North America:
Bosch Security Systems, LLC
130 Perinton Parkway
Fairport, New York, 14450, USA
Phone: +1 800 289 0096
Fax: +1 585 223 9180
onlinehelp@us.bosch.com
www.boschsecurity.com

Asia-Pacific:
Robert Bosch (SEA) Pte Ltd, Security Systems
11 Bishan Street 21
Singapore 573943
Phone: +65 6571 2808
Fax: +65 6571 2699
www.boschsecurity.com/xc/en/contact/
www.boschsecurity.com